

INSTRUCTIONS FOR USE OF  
CLASS II BIOLOGICAL SAFETY CABINET

TURN BLOWER ON 15 MINUTES PRIOR TO USE  
DISINFECT INTERIOR SURFACES BEFORE WORK  
COMMENCES

PLACE EQUIPMENT/SUPPLIES INTO CABINET

ALLOW 2-3 MINUTES FOR THE CABINET TO  
PURGE AFTER PLACING MATERIALS IN IT

SLEEVES MUST BE WORN WHILE WORKING

DISINFECT INTERIOR SURFACES UPON  
COMPLETION OF WORK

SC #044.2  
Eff. 6/17

4 X 6